


# Portable Nail Drill


## User Manual



**JMD-219C**

### NAIL DRILL SYSTEM

- 1 On/Off
- 2 Speed Display
- 3 OEM Logo
- 4 Forward/Reverse Display
- 5 Handpiece
- 6 Charging Port
- 7 Handpiece Jack
- 8 Forward/Reverse
- 9 Speed Knob/Pause
- 10 Bit Holder
- 11 Handpiece Holder
- 12 Charging Stand
- 13 Power Adapter Port



## SPECIFICATION

1.Model:JMD-219C

2.Power:48W

3.Input:AC100-240V 50/60HZ

4.Output:AC3-12V

5.Battery Capacity:2600mAh 74V

6.Dimension:228\*233\*71mm

7.Speed:0-35000RPM

## PACKING LIST

1\*Main Machine

1\*Handpiece


1\*Nail Drill Bits

1\*Adaptor


1\*User Manual

1\*Charging stand


## SET DRILL BITS




① Turn left side clockwise until you hear it click into the place



② Take out the original bit



③ Insert the 3/32"size bit





④ Turn right side anti-clockwise to lock the bit tightly

## PRECAUTION

- 1.Do NOT disassemble the handpiece.
- 2.Do NOT drop the handpiece.
- 3.Do NOT work in a humid environment.
- 4.Operating Environment Humidity: 30%-75%.
- 5.Operating Environment Temperature: +10°C~26°C.
- 6.Turn off the power when changing the bits.
- 7.Make sure the power switch is off before plugging in the power cord to avoid an unexpected injury due to sudden start.

## OPERATION STEPS

- 1.When you press On/Off button,the alternate light is on, the machine enter into the standby state.
- 2.When you turn the knob, the speed will adjust from 00-35 (RPM\*1000)and 35-00 (RPM\*1000),you can adjust to the desired speed.
- 3.When you turn "  " button to adjust forward and reverse of the handpiece.
- 4.When you press "  " button, the handpiece enters the pause state. Press the pause button again to release the pause.
- 5.If the battery is running out of power ,please charge it in time. Please pay attention that you shall charge it with 12V==2A power adapter, otherwise it will cause the machine breakdown.